

## USA SPEC Application Guide

## 6 Disc Changers

Last Updated: 02-04-03

Make	Model	Year	Changer	Required Cable	Notes
Acura	Integra	92 - 01	SCD - A88i	CDL - H7	Connector is behind the radio
	Legend, Vigor	91 - 97	SCD - A88i	CDL - H7	Pre-wired. Connector is in left-rear of trunk
	SLX	98 - 00	SCD - T170i	CDL - TYi	Connector is behind the radio
Audi	A4, Cabriolet	98 - 02	SCD - VW44E	CAS - AD	13-pin din in left-rear trunk. 98-99 vehicles, radio must have rounded PWR button in the middle.
	A6, A8	98 - 02	SCD - VW44E	CAS - AD	13-pin din in left-rear trunk.
	TT	00 - 01	SCD - VW44E	CAS - AD	13-pin connector behind the left-rear window panel.
BMW	3 Series	96 - 03	SCD - B2i	CAS - BMi	Pre-wired. Left-rear trunk. <b>Except 96 318ti and all vehicles with GPS system.</b>
	Z3/Z4	99 - 03	SCD - B2i	CAS - BMi	Pre-wired. Z3/Right-rear trunk. Additional parts may needed. Z4/Rear compartment between rear spks
	X & 5 Series	98 - 03	SCD - B2i	CAS - BMi	Pre-wired. Left-rear trunk. <b>Except vehicles with GPS.</b>
	7 Series	99 - 01	SCD - B2i	CAS - BMi	Pre-wired. Left-rear trunk. <b>Except cars with GPS.</b>
	Mini	02 - 03	SCD - B2i	CAS - BMi	Pre-wired. Right-rear trunk.
Buick	Century	97 - 03	SCD - G190V5	CDL - GB	Connector at radio. Radio must have SOURCE button.
	Le Sabre	97 - 99	SCD - G190V5	CDL - GB	Connector at radio. Radio must have SOURCE button.
	Park Ave./ Roadmaster	97 - 03	SCD - G190V5	CDL - GB	Connector at radio. Radio must have SOURCE button.
	Regal	97 - 03	SCD - G190V5	CDL - GB	Connector at radio. Radio must have SOURCE button.
Cadillac	Catera	97 - 01	SCD - G190V5	CAS - GCAD	Pre-wired in right-rear trunk. If not , data cable must be purchased from Cadillac #16244353
	DeVille	97 - 01	SCD - G190V5	CAS - GCAD	Pre-wired. 97-99 in right-rear-trunk. 00-01 behind glove-box.
	Seville	97 - 01	SCD - G190V5	CAS - GCAD	Pre-wired. 97-99 in right-rear trunk or center console. 00-01 behind glove-box or center console.
	Eldorado	97 - 01	SCD - G190V5	CAS - GCAD	Pre-wired. 97-99 in right-rear trunk or center console. 00-01 behind glove-box or center console.
	Escalade	99 - 02	SCD - G190V4	CDL - GCOS	Connector at radio or slave CD/cassette player
Chevrolet	Camaro/Cavalier	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. 9-pin plug at radio.
	Camaro	00 - 02	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.
	Cavalier	00 - 03			Not compatible with G190V4.
	Impala/Monte Carlo	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. 9-pin plug at radio.
	Impala/Monte Carlo	00 - 03			Not compatible with G190V4.
	Malibu	97 - 00	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. 9-pin plug at radio.
	Malibu	01 - 03			Not compatible with G190V4.
<b>99 and earlier AM/FM/CD player will not control cd changer. 00-02 AM/FM/CD player will control cd changer and slave cassette. No cdc for 2003 is available at this time.</b>					
Chevy Trucks	Astro/Cargo Van	97 - 01	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. 9-pin plug at radio.
	Avalanche	2002	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.
	Blazer/S-10 Truck/Venture	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave unit must be disconnected. 9-pin plug at radio.
	Blazer/S-10 Truck	00 - 01	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.
	Silverado	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave unit must be disconnected. 9-pin plug at radio.
	Silverado	00 - 02	SCD - G190 V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.
	Tahoe/Suburban	97 - 99	SCD - G190 V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. AM/FM/CD will not control changer. Slave CD must be disconnected.
Tahoe/Suburban	00 - 02	SCD - G190 V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.	
<b>99 and earlier AM/FM/CD player will not control cd changer. 00-02 AM/FM/CD player will control cd changer and slave cassette. No cdc for 2003 is available at this time.</b>					
Chrysler	300M, LHS	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.
		98 - 01	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.
	Concorde	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.
		98 - 01	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.
		95 - 97	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.
	PT Cruiser	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.
		2001	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.
	Sebring	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.
		2001	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.
		95 - 00	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.
	Town&Country/Voyager	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio. Except vehicles with OEM DCD system.
2001		SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
95 - 00		SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
Daewoo	Lanos	00 - 02	SCD - D50	CDL - DW	<b>Fits all radios with CD button (not for radios with CDC button)</b>
	Leganza	00 - 02	SCD - D50	CDL - DW	<b>Fits all radios with CD button (not for radios with CDC button)</b>
	Nubria	00 - 02	SCD - D50	CDL - DW	<b>Fits all radios with CD button (not for radios with CDC button)</b>

\*\* Products are designed to be compatible with factory systems. However, products are not designed to be factory replacement parts. Please consult owner's manual for specifications.

\*\* Product Please co

## USA SPEC Application Guide

Make	Model	Year	Changer	Required Cable	Notes	Last Updated: 02-04-03
Dodge	Caravan	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio. Except vehicles with OEM DVD system.	
		2001	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
	Dakota	95 - 00	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
		02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
		2001	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
	Durango	98 - 00	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
		02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
		2001	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
	Intrepid	95 - 00	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
		02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
		98 - 01	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
	Neon	95 - 97	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
		02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
		00 - 01	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
	Stratus	95 - 99	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
		02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
		2001	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
	Ram	95 - 00	SCD - A88i	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
		02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
		95 - 01	SCD - A881	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
Ford/ Lincoln/ Mercury	<b>C.Victoria/G.Marquis</b>	<b>2003</b>	<b>SCD - F100i</b>	<b>CDL - F24</b>	<b>Connect behind the radio.</b>	
	C.Victoria/G.Marquis	98 - 02	SCD - F100i	CDL - F20	For CDC control radio only	
	C.Victoria/G.Marquis	96 - 97	SCD - F100i	CDL-F16/F10	For CDC control radio only. JBL or LUX audio system use F10 cable.	
	<b>Escape/Mustang</b>	<b>01 - 03</b>	SCD - F100i	CDL - F20	For CDC control radio only	
	Econoline	<b>98 - 03</b>	SCD - F100i	CDL - F20	For CDC control radio only	
	Econoline	96 - 97	SCD - F100i	CDL - F16	For CDC control radio only	
	Excursion	00 - 03	SCD - F100i	CDL - F20	For CDC control radio only	
	<b>Expedition</b>	<b>2003</b>	SCD - F100i	CDL - F20	For CDC control radio only	
	Expedition/Navigator	99 - 02	SCD - F100i	CDL - F20	For CDC control radio only	
	Expedition/Navigator	96 - 98	SCD - F100i	CDL-F16/F10	For CDC control radio only. JBL or LUX audio system use F10 cable.	
	<b>Explorer/Mountaineer</b>	<b>98 - 03</b>	SCD - F100i	CDL - F20	For CDC control radio only. <b>Some 02-03 AM/FM CD players are not CDC control radios</b>	
	Explorer/Mountaineer	96 - 97	SCD - F100i	CDL-F16/F10	For CDC control radio only. JBL or LUX audio system use F10 cable.	
	<b>F-series Truck</b>	<b>98 - 03</b>	SCD - F100i	CDL - F20	For CDC control radio only	
	F-series Truck	96 - 97	SCD - F100i	CDL - F16	For CDC control radio only	
	<b>Ranger PU</b>	<b>98 - 03</b>	SCD - F100i	CDL - F20	For CDC control radio only. <b>Some 02-03 AM/FM CD players are not CDC control radios</b>	
	Ranger PU	96 - 97	SCD - F100i	CDL - F16	For CDC control radio only	
	<b>Sport Trac</b>	<b>00 - 03</b>	SCD - F100i	CDL - F20	For CDC control radio only	
	<b>Windstar/ Villager</b>	<b>99 - 03</b>	SCD - F100i	CDL - F20	For CDC control radio only	
	Windstar/ Villager	96 - 98	SCD - F100i	CDL - F16	For CDC control radio only	
	<b>TownCar</b>	<b>2003</b>	<b>SCD - F100i</b>	<b>CDL - F24</b>	<b>Connect behind the radio.</b>	
	<b>TownCar</b>	<b>2003</b>	<b>SCD - F100i</b>	<b>CAS - F14*</b>	<b>For pre-wired cars only.</b>	
	Continental/TownCar	98 - 02	SCD - F100i	CDL - F20	For CDC control radio only	
	Continental/TownCar	96 - 97	SCD - F100i	CDL-F16/F10	For CDC control radio only. JBL or LUX audio system use F10 cable.	
	LS	00 - 02	SCD - F100i	CDL - F20	For CDC control radio only	
	Cougar	99 - 02	SCD - F100i	CDL - F12	For CDC control radio only	
	Focus	00 - 02	SCD - F100i	CDL - F12	For CDC control radio only	
	<b>Taurus/Sable</b>	<b>97 - 03</b>	SCD - F100i	CDL - F10	For CDC control radio only	
<b>All models 96-03, use CAS-F14 cable if pre-wired.</b>						
GMC	Safari/Cargo Van	97 - 01	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. 9-pin plug at radio.	
	Jimmy/Sonoma	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. 9-pin plug at radio.	
		00 - 01	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.	
	Sierra	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. 9-pin plug at radio.	
		00 - 02	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.	
	Yukon/Denali	97 - 99	SCD - G190 V4	CDL - GCOS	AM/FM/TAPE radio with AUX only. AM/FM/CD will not control changer. Slave CD must be disconnected.	
		00 - 02	SCD - G190 V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.	
<b>99 and earlier AM/FM/CD player will not control cd changer. 00-02 AM/FM/CD player will control CD changer and slave cassette. No CDC for 2003 is available at this time.</b>						

## USA SPEC Application Guide

Make	Model	Year	Changer	Required Cable	Notes	Last Updated: 02-04-03
Honda	<b>Accord/Element</b>	<b>2003</b>	<b>N/A</b>		<b>No application at this time.</b>	
	Accord	98 - 02	SCD - A88i	CDL - H8	14-pin connector at radio. Not for 03 Accord.	
		94 - 97	SCD - A88i	CDL - H7	8-pin din connector at radio.	
	Civic	99 - 03	SCD - A88i	CDL - H8	Slave OEM CDP must be disconnected if there is one. 14-pin connector at radio or slave cassette.	
		94 - 98	SCD - A88i	CDL - H7	Slave OEM CDP must be disconnected if there is one. 8-pin connector at radio or slave cassette.	
	CRV/Odyssey/Prelude	99 - 03	SCD - A88i	CDL - H8	14-pin connector at radio.	
		95 - 98	SCD - A88i	CDL - H7	8-pin din connector at radio.	
	Passport	98 - 02	SCD - T170i	CDL - TYi	Connector at radio.	
	<b>Pilot</b>	<b>2003</b>	<b>SCD - A88i</b>	<b>CDL - H8</b>	<b>Except Vehicles equip with NAV. And Video Systems.</b>	
Hyundai	Sonata	00 - 01	SCD - H1	CDL - HY	For double din radio with CD/CHG or single din AM/FM/CD radio with disc button.Connector at radio.	
	Sonata	02 - 03	MCD - C60	CDL - HY	For double din radio with CD/CHG or single din AM/FM/CD radio with disc button.Connector at radio.	
	Sante Fe	00 - 03	SCD - H1	CDL - HY	Not compatible with 03 Delco/Bose system	
	XG300/XG350	00 - 03	SCD - H1	CDL - HY	For double din radio with CD/CHG or single din AM/FM/CD radio with disc button.Connector at radio.	
	Tiburon	2003	MCD - C60	CDL - HY	For double din radio with CD/CHG button.Connector at radio.	
Infiniti	All Models	99 - 01	SCD - N66E	CDL - NS	Connector is behind the radio	
	All Models	96 - 98	SCD - N66	CDL - NS	<b>96-97 Q45 may have different power plug. Call tech suport@626 890 6410</b>	
Isuzu	Amigo	98 - 02	SCD - T170i	CDL - TYi	Radio must have DISC button	
	Rodeo	98 - 02	SCD - T170i	CDL - TYi	Radio must have DISC button	
	Trooper	98 - 02	SCD - T170i	CDL - TYi	Radio must have DISC button	
Jaguar	<b>S - Type only</b>	<b>00 - 02</b>	<b>SCD - F100i</b>	<b>CDL - F12</b>	<b>Connector behind the radio.</b>	
Jeep	G. Cherokee	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
		99 - 01	SCD - C130i	CDL - CXi	Radio must have CD-C button. 8-pin din connector at radio.	
		95 - 98	SCD - A88	CDL - CJ	For rectangle am/fm/tape radio with MODE/CD. 8-pin din connector at radio.	
	<b>Wrangler</b>	2003	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
	Liberty	02 - 03	SCD - C130i	CDL - CXi	Radio must have MODE button. 10-pin square plug at radio.	
Mercedes	All models	99 - 02	A203	fiber	See Fiber optic A203 application.	
	C-class	94 - 98	SCD - A88i	CAS - M4	10-pin connector in right-rear trunk behind quarter panel.	
	E-class	94 - 98	SCD - A88i	CAS - M4	10-pin connector in right-rear or left-rear trunk quarter panel.	
	SL	94 - 98	SCD - A88i	CAS - M4	10-pin connector in left-rear trunk behind quarter panel.	
	S-class	94 - 99	SCD - A88i	CAS - M4	10-pin connector in left-rear trunk behind quarter panel.	
	Nissan	Maxima	99 - 01	SCD - N66E	CDL - NS	For double din radio with CD/ CHG button only.
		95 - 98	SCD - N66	CDL - NS	For double din radio with CD/ CHG button only.	
Altima		99 - 01	SCD - N66E	CDL - NS	For double din radio with CD/ CHG button only.	
		95 - 98	SCD - N66	CDL - NS	For double din radio with CD/ CHG button only.	
Frontier		99 - 01	SCD - N66E	CDL - NS	For double din radio with CD/ CHG button only.	
Sentra		99 - 00	SCD - N66E	CDL - NS	For double din radio with CD/ CHG button only.	
		96 - 98	SCD - N66	CDL - NS	For double din radio with CD/ CHG button only.	
Quest		99 - 02*	SCD - F100i	CDL - F20/F14	<b>*Use F14 cable for roof mounted Monitor, F20 for Console mounted Monitor 2001 - 2002.</b>	
		96 - 98	SCD - F100i	CDL - F16	Connector at radio.	
Oldsmobile		Alero	99 - 00	SCD - G190V4	CDL - GB	Radio must have SOURCE or AUX button. 32-pin connector behind the radio.
	Aurora	97 - 99	SCD - G190V4	CDL - GB	Radio must have SOURCE or AUX button. 32-pin connector behind the radio.	
	Intrigue	98 - 01	SCD - G190V4	CDL - GB	Radio must have SOURCE or AUX button. 32-pin connector behind the radio.	
	Bravada	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
	Silhouette	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
Pontiac	Bonneville	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
	Firebird	00 - 02	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.	
		97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
	Grand Am	2000	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.	
		97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
	Grand Prix	00 - 01	SCD - G190V4	CDL - GCOS	9-pin plug at radio or at slave tape unit. Compatible with On-Star system.	
		97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
	Montana	98 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
	Sunfire	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
	Trans Sport	97 - 99	SCD - G190V4	CDL - GCOS	AM/FM/TAPE radio with AUX only.Slave unit must be disconnected. 9-pin plug at radio.	
Plymouth	All Models	96 - 99	SCD - A88i	CDL - CJ	For Casette/Radio with CD button only.	
Volvo	All Models	94 - 00	SCD - A88i	CDL - VOL	Except S80. 2 wires come from CDL VOL: Yellow is Battery+, red is Acc.+	
	C 70	01 - 02	SCD - A88i	CDL - VOL	2 wires come from CDL VOL: Yellow is Battery+, red is Acc.+	

## USA SPEC Application Guide

Make	Model	Year	Changer	Required Cable	Notes	Last Updated: 02-04-03
Saturn	All Models	96 - 99	SCD - G190V4	CDL - GS	For radios that has AUX button. If pre-wired, use CAS GD cable	
	L and S-Series	00 - 01	SCD - S20	CDL - GNS	For double din radio with CD/ TP button only. S series Insert 5A fuse for CDC in fuse box	
Toyota	<b>Mr2 / Celica</b>	<b>2003</b>	<b>SCD - T170i</b>	<b>see notes</b>	<b>Connector behind radio. CDL-TYi and CAS-TA cables are required.</b>	
	Mr2 / Celica	98 - 02	SCD - T170i	CDL - TYi	Connector behind radio.	
	<b>Rav4</b>	<b>2003</b>	<b>SCD - T170i</b>	<b>see notes</b>	<b>Connector behind radio. CDL-TYi and CAS-TA cables are required.</b>	
	Rav4	98 - 02	SCD - T170i	CDL - TYi	Connector behind radio.	
	Avalon	98 - 03	SCD - T170i	CDL - TYi	Connector behind radio.	
	Camry / Solara	98 - 03	SCD - T170i	CDL - TYi	Connector behind radio.	
	Corolla / Echo	98 - 03	SCD - T170i	CDL - TYi	Connector behind radio.	
	<b>Sequoia / Tundra</b>	<b>2003</b>	<b>SCD - T170i</b>	<b>see notes</b>	<b>Connector behind radio. CDL-TYi and CAS-TA cables are required.</b>	
	Sequoia / Tundra	98 - 02	SCD - T170i	CDL - TYi	Connector behind radio.	
	Land Cruiser	98 - 01	SCD - T170i	CDL - TYi	Connector behind radio.	
	<b>4 Runner</b>	<b>2003</b>	<b>SCD - T170i</b>	<b>see notes</b>	<b>Connector behind radio. CDL-TYi and CAS-TA cables are required.</b>	
	4 Runner	98 - 02	SCD - T170i	CDL - TYi	Connector behind radio.	
	Highlander	01 - 03	SCD - T170i	CDL - TYi	Connector behind radio.	
	Sienna	98 - 03	SCD - T170i	CDL - TYi	Connector behind radio. Hook up 2-wires of steering wheel control with CDL-TYi cable in parallel.	
Tacoma	98 - 03	SCD - T170i	CDL - TYi	Connector behind radio.		
<b>SCD-T170E/T170i is NOT compatible with vehicles that are equipped with OEM NAV. OR VIDEO SYSTEMS.</b>						

Volkswagen	Cabrio	98 - 03	SCD-VW44E	CAS-VW	<b>Pre-wired at right-rear trunk. One brown wire has to be grounded from OEM CD changer plug.</b>
	<b>Bettle Convertible</b>	<b>2003</b>	<b>SCD - VW44E</b>	<b>CDL-VW</b>	<b>Connector behind the radio.</b>
	Bettle	98 - 03	SCD-VW44E	CAS-VW	Pre-wired at left-rear trunk behind small black plastic cover.
	Golf	98 - 03	SCD-VW44E	CAS-VW	Pre-wired at left-rear trunk behind storage door.
	GTI	98 - 03	SCD-VW44E	CAS-VW	Pre-wired at left-rear trunk behind storage door.
	Jetta	98 - 03	SCD-VW44E	CAS-VW	Pre-wired at left-rear trunk behind storage door.
	Passat	98 - 03	SCD-VW44E	CAS-VW	Pre-wired at left-rear trunk behind storage door.
	<b>EuroVan</b>	<b>01 - 03</b>	<b>SCD-VW44E</b>	<b>CDL-VW</b>	<b>Connector behind the radio.</b>

**Radios in all vehicles must have round SCAN button. Some 98-99 vehicles with BOSE or PREMIER radios that have 13-pin din plug in trunk are not compatible with SCD-VW44E**

## Single Disc Players

Make	Model	Year	Player	Required Cable	Notes
Acura	Integra	94 - 97	ICD - H107E	Included	May require custom-made bracket to secure the ICD-H107E.
Honda	Accord	98 - 02	ICD - H108E	Included	Mount underneath the radio.
	Accord	94 - 97	ICD - H107E	Included	May require custom-made bracket to secure the ICD-H107E.
	Civic	01 - 03	ICD - H200	Included	Slave/External cassette must be removed in order to installing ICD-H200 if there is one.
	Civic	99 - 00	ICD - H108E	Included	Slave/External cassette must be removed in order to installing ICD-H108E if there is one.
	Civic/CRV	94 - 98	ICD - H107E	Included	May not fit some 94-96 Civic if there is no din-size opening in the dash or underneath the dash.
	CRV	99 - 03	ICD - H108E	Included	Mount underneath the radio.
	Passport	98 - 02	<b>ICD - T107E</b>	Included	Mount underneath the radio.
	Odyssey	99 - 03	ICD - H108E	Included	For AM/FM/Tape Radio only. Not compatible with OEM NAV. Or DVD system.
	Odyssey/Prelude	95 - 98	ICD - H107E	Included	May require custom-made bracket to secure the ICD-H107E.
Isuzu	Rodeo	98 - 02	ICD - T107E	Included	Radio must have DISC button.
	Trooper	98 - 02	ICD - T107E	Included	Radio must have DISC button.
	Amigo	00 - 02	ICD - T107E	Included	Radio must have DISC button.
Toyota	All Models	98 - 99	ICD - T107E	Included	For single din AM/FM/CASS radio only
	Corolla *	98 - 02	ICD - T107E	Included	For single din AM/FM/CASS radio only
	RAV4	98 - 00	ICD - T107E	Included	For single din AM/FM/CASS radio only

\* Corolla 1998-2002 Pocket may be required to fill up dash space, it can be purchased from Metra ( Part number 88-000-8000)